



NOTES:

1. COMPLETE FREE BORE. REMOVE AUGER, AND INSERT CARRIER PIPE W/ SPIGOT END.
2. PROVIDE SINGLE PIECE OF CARRIER PIPE FOR ENTIRE SPAN OF FREE BORE WITH NO JOINTS.